

# Rhino OE200 Wine Tester:

## Accurate, portable, rugged refractometer

### Helps maximize your profits.

The Reichert Rhino OE200 Wine Tester is a hand-held refractometer that gives you fast and accurate measurements of dissolved sugars. The sharp, high-contrast scale provides quick and easy readings when testing grapes, citrus fruits, fruit juices, soft drinks, melons and maple sap. Using this rugged instrument to measure sugar levels at harvest time eliminates guesswork and helps you maximize profits.

#### KEY FEATURES

- Scales for Oechsle (Oe°), Brix (% Sucrose) and Klosterneuburger (Kl°)
- Automatic temperature compensation provides accurate readings without correction tables or temperature measurement
- IP67 dustproof and water resistant performance and shock resistant durability make this instrument at home in the field, vineyard or lab
- Large, easy-to-read scales



#### RHINO OE200 WINE TESTER

Catalog Number	137528L0
Range	Oe° 0 - 200 Brix 0 - 45 Kl° 0 - 40
Scale Divisions	Oe° 2 and 5 Brix 0.5 Kl° 0.5
Refractive Index Range	1.3330 - 1.4100
Calibration Liquid	Distilled Water



Analytical Instruments

Reichert, Inc., 3362 Walden Avenue, Depew, NY 14043  
Tel: (716) 686-4500 -- Fax: (716) 686-4555  
e-mail: ai@reichert.com -- [www.reichertai.com](http://www.reichertai.com)